


AD-8541-PC

パソコン用ワイヤレス通信インターフェース

取扱説明書

ご注意

- 本書の一部または全部を無断転載することは固くお断りします。
- 本書の内容については将来予告なしに変更することがあります。
- 本書の内容は万全を期して作成しておりますが、ご不明な点や誤り、記載漏れなどお気づきの点がありましたら、ご連絡ください。
- 当社では、本器の運用を理由とする損失、損失利益等の請求については、前項にかかわらずいかなる責任も負いかねますのでご了承ください。



1. 安全かつ正しく使用するための注意

この機器を操作するときは、下記の点に注意してください。

⚠注意 本体を分解しないでください。機器を損傷し機能を失う恐れがあり、保証の対象外となります。

⚠注意 本製品は、無線通信を行うため、その国の電波法の認証が必要です。海外の認証状況については、参考資料をホームページに掲載予定です。


2. はじめに

AD-8541-PC パソコン用ワイヤレス通信インターフェースは、パソコンのUSBに接続して通信相手（弊社の計量機器）とBluetooth通信をするためのインターフェースです。使用前に取扱説明書(本書)をお読みください。

3. 各部名称

接続用スイッチ
数秒間長押しして、通信相手とのペアリングを行います。

状態表示 LED
パソコンに接続すると、状態表示 LED で AD-8541-PC の状態を確認できます。



状態表示 LED		本製品の状態
色	点灯状態	
緑	点灯	通信相手をスキャン中です。
緑	点滅	通信相手と通信中です。
オレンジ	点滅	通信相手とペアリング中です。 (通信相手をスキャン中)
赤	点滅	エラー状態

梱包内容 AD-8541-PC…1 個 取扱説明書(本書)…1 冊

4. ペアリング方法

初めて使用する場合、次の手順でペアリングを行ってください。また、ペアリングの対象が分からなくなってしまった場合も、以下の手順で再度ペアリングを行うことが可能です。

手順1. 本製品をパソコンに接続し、接続用スイッチを状態表示 LED がオレンジ色に点滅するまで（約3〜4秒程度）長押しします。

手順2. 通信相手（弊社の計量機器）の電源をオンにして、しばらくそのままお待ちください。複数の通信機器がある場合、接続対象以外の電源を切ってください。

手順3. 状態表示 LED が緑の点滅に変わればペアリングおよび、接続が完了です。

5. 使い方

注意

本製品を使用するにはパソコンにドライバーのインストールが必要です。ドライバーのインストールはパソコンへの初回接続時のみです。「10. ドライバーのインストール方法」を参照してください。パソコン以外のUSBポートに挿さないでください。

手順1. 本製品をパソコンのUSBポートに接続します。

手順2. 状態表示 LED が緑色に点灯していることを確認してください。上記の色のLEDが点灯していない場合は、「6. 故障かな? と思ったら」を参照してください。

手順3. 通信相手との接続が完了するとLEDが緑色の点滅に変わります。

手順4. パソコン上で WinCT 等のアプリケーションを起動することで通信が可能となります。COM ポートの番号はデバイスマネージャにて USB Serial Port と表示される番号を確認してください。通信設定は、「7. 仕様」を参照してください。

6. 故障かな? と思ったら

通信ができない時の主な対処一覧

確認箇所	対処の仕方
状態表示 LED は、緑色の点灯ですか?	通信相手側の電源を入れ直し、接続スイッチを長押しします。
状態表示 LED は、緑色の点滅ですか?	通信相手側の電源を入れ直し、ペアリングを行います。「4. ペアリング方法」参照。
パソコンにドライバーがインストールされていますか?	ドライバーをインストールしてください。「10. ドライバーのインストール方法」参照。
パソコンと通信相手の設定は、正しいですか?	パソコンでお使いのアプリケーションの設定と AD-8541-PC を確認します。
アプリケーションに正しい COM ポートが表示されていますか?	AD-8541-PC を挿し直し、正しい COM ポートの表示を確認します。
パソコン以外の USB ポートに挿していませんか?	パソコンの USB ポートに挿してください。

7. 仕様

通信距離	最大 10 m
専用電源	不要 (USB ポートより給電)
接続可能機器	弊社の無線通信に対応した製品 ※1
対応 OS	Windows XP/VISTA/7/8.1/10 (32bit, 64bit 両対応) ※2
動作温湿度範囲	-10 ~ 40 °C、85 %RH 以下 (結露しないこと)
寸法	約 24 mm (W) × 12 mm (H) × 74 mm (D)
質量	約 15 g
無線通信	EYSHCNZXZ (太陽誘電株式会社) Bluetooth 4.2 (Bluetooth Low Energy)
設定	ボーレート: 2400 bps ビット長/パリティ: 7 bit / even ストップビット: 1 bit

- ※1 Bluetooth 対応の製品は、弊社ホームページよりご確認ください。
- ※2 Windows は、米国およびその他の国における米国 Microsoft Corporation の登録商標または商標です。

8. 電波に関する注意事項

本製品には、電波法に基づく小電力データ通信システムの無線局として、工事設計認証を受けた無線設備を内蔵しています。本製品の使用周波数帯では、移動体識別用の構内無線局及び特定小電力無線局並びにアマチュア無線局が運営されています。

- 本製品を使用する前に、近くで移動体識別用の構内無線局等が運用されていないことを確認してください。
- 万一、本製品から移動体識別用の構内無線局に対して有害な電波干渉の事例が発生した場合には、電波の発射を停止し混信回避のための処置等を行ってください。

2.4FH1	2.4 : 「2.4 GHz 帯を使用する無線設備」を表す。
⋮	FH : 「FH-SS 方式」を示す。
⋮	1 : 「想定される干渉距離が 10 m 以下」を示す。
⋮	⋮ : 2.4 GHz 帯全帯域を使用し、移動識別装置の帯域を回避不可であることを意味する。
Ⓜ	EYSHCN : 001-A07225

9. Bluetooth 通信

本製品をご使用の際は、見通し距離 10 m 以下で通信してください。壁等の障害物がある場合の無線通信は、通信距離が短くなります。2.4 GHz 帯の電波を使用している下記の機器の近くでは、干渉を起す可能性があり、信頼性を重視するご使用には適しません。

- 無線 LAN
- Bluetooth 搭載機器 (携帯電話等)
- 電子レンジ等家電製品

10. ドライバーのインストール方法

Windows 8.1 以降は、Windows Update でドライバーのインストールが自動的に行われます。自動的にドライバーのインストールができない場合、弊社ホームページの [サポート]→[ソフトウェアダウンロード] より入手してください。また、インストール方法は、ダウンロードした圧縮ファイルに有る説明書を参照してください。弊社ホームページ <http://www.aandd.co.jp/>

保証書

この度は弊社の製品をお買い上げ頂きありがとうございました。未永くご愛用頂くため、弊社の点検サービスをお勧めいたします。下記の通り製品に限り保証いたしますので、この保証書は大切に保管しておいてください。

記

- 正常な使用状態において製造上の責任による故障は、納品日より1年間無償にて修理いたします。ただし、製品の運用を理由とする損失、損失利益等のご請求には前記にかかわらずいかなる責任も負いかねますのでご了承ください。
- 次のような場合には保証期間内でも有償修理といたします。
 - 不適当な取扱または使用による故障。
 - 弊社または弊社が委託した者以外による改造または修理に起因する故障。
 - 火災、地震、水害、異常気象、その他の天災地変をはじめ、故障の原因が本製品以外の理由による故障または損傷。
 - 取扱説明書に記載されている必要な設置条件、及び保守が満たされない場合。
 - ご使用後の外装面の傷、破損、外装部品、付属品の交換。
- 本保証書は日本国内においてのみ有効です。
 - ※ お買い上げ店または弊社営業所にご持参いただくに際しての諸費用は、お客様がご負担願います。

品名	エー・アンド・デイ パソコン用ワイヤレス通信インターフェース
型名	AD-8541-PC
お客様お名前様	
ご住所	□□□-□□□□
ご購入日	年 月 日
ご購入店 (ご購入店名を必ずご記入ください)	
保証期間	ご購入日より1年間
本社	〒170-0013 東京都豊島区東池袋3-23-14 (ダイハツ・ニッセイ池袋ビル5F)
TEL	03-5391-6126 (代) FAX 03-5391-6129

使い方・修理に関するお問い合わせ窓口

故障、別売品・消耗品に関してのご質問・ご相談も、この電話で承ります。修理のご依頼、別売品・消耗品のお求めは、お買い求め先へご相談ください。

お客様相談センター

電話 **0120-514-019** 通話料無料
受付時間: 9:00~12:00, 13:00~17:00, 月曜日~金曜日(祝日・弊社休業日を除く) 都合によりお休みまたは、受付時間を変更させて頂くことがありますのでご了承ください。
※ 電話番号は、2016年11月11日現在です。
※ 電話番号は、予告なく変更される場合があります。
※ 電話のかけまちかへご注意ください。番号をよくお確かめの上、おかけください。

AD-8541-PC

Wireless Communication Interface



A&D Company, Ltd.

INSTRUCTION MANUAL

Note

© 2017 A&D Company, Limited. All rights reserved.

- No part of this publication may be reproduced, transmitted, transcribed, or translated into any language in any form by any means without the written permission of A&D.
- The contents of this manual and the specifications of the instrument covered by this manual are subject to change for improvement without notice.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by A&D is under license.

1WMPD4003796

1. Compliance

1.1. Compliance with FCC Rules

This device contains transmitter module FCC ID : RYYEYSHCN
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. (FCC = Federal Communications Commission in the U.S.A.)

FCC warning

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note :

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his / her own expense.

1.2. IC

IC RADIATION EXPOSURE STATEMENT FOR CANADA

This device complies with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions : (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device contains transmitter module IC : 4389B-EYSHCN

2. Precautions

Consider the following cautions when the AD-8541-PC is used.

- △Caution Do not disassemble the device. Doing so may damage the device and cause failure, and the warranty will void.

3. Outline and Features

The AD-8541-PC is a wireless communication interface that connects to a USB port of a computer and can communicate with A&D weighing instruments equipped with Bluetooth. Read this manual before use.


4. Names

Connection switch

Press and hold the switch for several seconds to start bluetooth pairing.

Monitoring LED

When the AD-8541-PC is connected to a USB port of a computer, the current status can be monitored using this LED.



Monitoring LED		Status of the AD-8541-PC
Color	Action	
Green	Lit	Scanning device
Green	Blinking	Communicating with device
Orange	Blinking	Pairing with (scanning) device
Red	Blinking	Error

Packing List

AD-8541-PC 1 Instruction manual (This manual) 1

5. Bluetooth Paring

Perform Bluetooth pairing before using for the first time in order to communicate with the device. Perform Bluetooth pairing again if connection with the device is lost.

- Step 1. Connect the AD-8541-PC to a USB port of a computer.
Press and hold the connection switch for approximately 3 to 4 seconds until the LED changes to blinking orange.
- Step 2. Turn on the weighing instrument to communicate with.
Wait for the LED to blink green. Turn off other Bluetooth devices if present.
- Step 3. When pairing is complete and the connection is established, the LED blinks green.

6. Use

Note

Install the driver software on the computer before using the AD-8541-PC. Installation only needs to be done once. Refer to "10. Installation of Driver Software". Do not connect to USB ports other than those of computer.

Step 1. Connect the AD-8541-PC to a USB port of a computer.

Step 2. Confirm that the monitoring LED is lit in green. If it is not lit in green, refer to "7. Check Before Calling for Service".

Step 3. When a connection has been established, the LED is blinks green.

Step 4. WinCT and other applications can communicate when they are run on the computer. Confirm the COM port number that is displayed for the USB serial port in the device manager.

Refer to "8. Specifications" concerning serial communication settings.

7. Check Before Calling for Service

Principal troubleshooting list for communication.

Check	Treatment
Is LED lit in green ?	Turn the device off and on again. Press and hold the connection switch.
Is LED blinking green ?	Turn the device off and on again. Perform pairing again. Refer to "5. Bluetooth Paring".
Is the driver software installed on the computer ?	Install driver software. Refer to "10. Installation of Driver Software".
Are communication settings correct ?	Confirm the settings of the computer application and AD-8541-PC.
Is the correct COM port displayed in the application ?	Insert AD-8541-PC again. Confirm that the correct COM port is the display.
Is the AD-8541-PC inserted into a USB port other than that of the computer?	Insert into a USB port of a computer.

8. Specifications

Communication range	Up to 10 m
Power supply	From USB port
Compatible communication devices	A&D weighing instruments equipped with Bluetooth #1
Operating system	Windows XP/Vista/7/8.1/10 (applicable to 32bit and 64bit) #2
Ambient operating temperature and humidity	-10 to 40 °C, Less than 85 %RH (No condensation)
Dimensions	Approx. 24 mm (W) × 12 mm (H) × 74 mm (D)
Mass	Approx. 15 g
Wireless communication	EYSHCNZYZ (TAIYO YUDEN CO. LTD.) Bluetooth 4.2 (Bluetooth Low Energy)
Parameters of serial communication	Baud rate : 2400 bps Bit length / Parity : 7 bit / even Stop bit : 1 bit

#1 Refer to the A&D website concerning applicable instruments equipped with Bluetooth.

#2 Windows is a registered trademark of Microsoft Corporation.

9. Bluetooth Communication

The effective range of Bluetooth communication is 10 m or less in an unobstructed space. If there is an obstacle such as a wall between Bluetooth devices, the range of communication will be shorter. Interference may be caused near the following devices that use the 2.4 GHz frequency band, which is the same as for Bluetooth. Therefore, this device is not suited for uses that require reliability.

- Wireless LAN
- Bluetooth devices (such as mobile phones)
- Home appliances such as microwave ovens

10. Installation of Driver Software

The driver software is automatically installed with Windows 8.1 or later. If the driver cannot be installed, download the software from [Support] - [Software] of the A&D website. Refer to the instruction manual included with downloaded files.

A&D website :

<http://www.aandd.jp/>